

Low NO_x self-recuperative burner ECOMAX® LE

OPERATING INSTRUCTIONS

· Edition 11.22 · EN · 03251612



CONTENTS

1 Safety	1
2 Checking the usage	1
3 Installation	2
4 Gas and air pipes	4
5 Wiring	5
6 Preparing commissioning	6
7 Commissioning	9
8 Maintenance	10
9 Assistance in the event of malfunction	13
10 Accessories	14
11 Technical data	15
12 Logistics	15
13 Declaration of Incorporation	15
14 Certification	16

1 SAFETY

1.1 Please read and keep in a safe place



Please read through these instructions carefully before installing or operating. Following the installation, pass the instructions on to the operator. This unit must be installed and commissioned in accordance with the regulations and standards in force. These instructions can also be found at www.docuthek.com.

1.2 Explanation of symbols

1, 2, 3, a, b, c = Action

→ = Instruction

1.3 Liability

We will not be held liable for damage resulting from non-observance of the instructions and non-compliant use.

1.4 Safety instructions

Information that is relevant for safety is indicated in the instructions as follows:

⚠ DANGER

Indicates potentially fatal situations.

⚠ WARNING

Indicates possible danger to life and limb.

⚠ CAUTION

Indicates possible material damage.

All interventions may only be carried out by qualified gas technicians. Electrical interventions may only be carried out by qualified electricians.

1.5 Conversion, spare parts

All technical changes are prohibited. Only use OEM spare parts.

2 CHECKING THE USAGE

ECOMAX LE is a self-recuperative burner for gas with integrated recuperator for the indirect heating of furnace systems in intermittent mode.

Combustion flue gases are separated from the product using metallic or ceramic radiant tubes and segmented ceramic flame tubes. This function is only guaranteed when used within the



specified limits – see page 15 (11 Technical data).
Any other use is considered as non-compliant.

2.1 Type code

ECOMAX LE	Low NOx self-recuperative burner
1, 2, 3	Burner size
C	With ceramic buried tube recuperator made of SiSiC
M	With cast steel ribbed tube recuperator
545–695	Recuperator length [mm]
-F	Low NOx operation flameless
B	Natural gas
/nnR-	For radiant tube heating without eductor for nn kW
/R-	For radiant tube heating without eductor
(1-99)	Burner head identifier
A-, B-,...	Construction stage
Z	Special version

2.2 Part designations


ECOMAX LE for radiant tube heating



- 1 Gas insert
- 2 Type label
- 3 Intermediate flange
- 4 Gaskets (set)
- 5 Air guide tube LFR (SiSiC)
- 6 Flue gas connector FLUP (to be ordered separately)
- 7 Burner body with internal insulation
- 8 Buried tube recuperator (SiSiC) or cast steel ribbed tube recuperator
- 9 Gas lance set for Flameless mode
- 10 Gas orifice with circlip
- 11 Air flange set
- 12 Enclosed documentation (flow rate curves, operating instructions, spare parts list, spare parts drawing)
- 13 Pressure flange
- 14 Gasket cord

2.3 Type label


Maximum burner capacity, gas type – see type label.



3 INSTALLATION

3.1 ECOMAX LE with ceramic radiant tube (SER-C)

- For an indirect heating system, the radiant tube SER-C, the FlameCone, the segmented flame tubes SICAFLEX® and the flue gas connector FLUP are required, see accessories.
- The FlameCone must be positioned at the outlet of the burner recuperator and is essential for flameless Low NO_x mode (first component in the SICAFLEX column). One FlameCone replaces two standard segmented flame tubes SICAFLEX.



Recirculation gap D1 (± 5 mm)

Type	C	M
	mm	
ECOMAX LE 1	15	30
ECOMAX LE 2	15	30
ECOMAX LE 3	30	30

- The ceramic radiant tube (SER-C) must be correctly installed on the furnace before the burner is installed, see www.docuthek.com.
- See www.docuthek.com for details of installing the internal FlameCone and the segmented flame tubes SICAFLEX.
- The FlameCone has 4 spacers (“feet”) for horizontal installation.
- Depending on the installation situation, a flue gas guide tube FGT set or an adapter flange may be required (available on request as accessories).


Installation of SER-C

⚠ CAUTION

Incorrect installation
Please observe the following to ensure that the ceramic radiant tube SER-C is not damaged during installation and operation:


- Open packaging carefully and without using force.
- Insert into the combustion chamber without any impacts or scratches to avoid damage and breakage. Depending on the furnace atmosphere during operation, damage to the protective oxide layer on the surface of the radiant tube can cause corrosion and thus reduce the service life.

- We recommend that someone be inside the combustion chamber to receive the radiant tube.
- For detailed information, refer to SER-C operating instructions.



3.2 ECOMAX LE with metallic radiant tube (SER-M)

- For an indirect heating system, the radiant tube SER-M, the FlameCone, the segmented flame tubes SICAFLEX® and the flue gas connector FLUP are required, see accessories.
- The FlameCone must be positioned at the outlet of the burner recuperator and is essential for flameless Low NO_x mode (first component in the SICAFLEX column). One FlameCone replaces two standard segmented flame tubes SICAFLEX.



- The metallic radiant tube (SER-M) must be correctly installed on the furnace before the burner is installed. Ensure there is a good seal between the burner and the radiant tube.
- See www.docuthek.com for details of installing the internal FlameCone and the segmented flame tubes SICAFLEX.
- The FlameCone has 4 spacers ("feet") for horizontal installation.
- Depending on the installation situation, a flue gas guide tube FGT set or an adapter flange may be required (available on request as accessories).

3.3 Installation in the furnace

⚠ CAUTION

Incorrect installation


Please observe the following to ensure that the ECOMAX LE is not damaged during installation and operation:

- Dropping the device can cause permanent damage. In this event, replace the entire device and associated modules before use.
- We recommend that lifting gear be used for installation due to the weight involved.
- Avoid impacts when inserting the burner into the radiant tube and placing on the stud bolts.
- The burner body features three connections to choose from for secondary air and one for flue gas. The primary air is connected to the gas insert. During installation, the burner must be aligned appropriately (flue gas upwards or to the side).


- On the ECOMAX LE, the ceramic air guide tube LFR and the gas lance set are supplied separately to protect them from transport damage.
- The ECOMAX LE is supplied with red notice flags which must be removed before the LFR is installed.
- Depending on the installation situation, the burner can be supplied with a flue gas guide tube FGT set or an adapter flange. The FGT set is available in the form of a shaped fibre part or in a metallic + fibre version.

- 1 Remove the transport safety device.
- 2 Remove the gas insert:

For size 1 and 2, remove the intermediate flange, including the gas insert



For size 3, remove the gas insert without the intermediate flange




- 3 Install the flue gas guide tube FGT set:


FGT set in the form of a shaped fibre part

- a Slide the FGT into the radiant tube (flush with the edge of the SER flange).


FGT set in metallic version with/without fibre



- b Remove and dispose of the backing foil.




- Wrap the FGT (metallic + fibre) in a ceramic fibre blanket. The wrapping thickness should be around twice the size of the gap dimension. Wrap the fibre blanket in adhesive tape so that the diameter fits into the radiant tube. After commissioning, the adhesive tape burns off and the fibre blanket expands evenly inside the annular void.




- Carry the FGT carefully and do not allow it to collide.

4 Install the burner housing with recuperator:



Sizes 1 and 2



- Take care not to hit the sides as you insert the ceramic recuperator into the radiant tube. Tighten the nuts in a crosswise fashion, torque: 46 Nm.
- When installing, ensure that the components are sealed tightly.
- b** Remove the transport safety device (3 x insulating tape) from the pressure flange (near the springs).




- Twist the recuperator as you insert it.
- d** Place the intermediate flange on the housing stud bolts and insert the LFR into the guide sleeve (intermediate flange).





- e** Press the gas insert into position, secure the nuts by hand and then tighten them in a crosswise fashion using a torque of 20 Nm.


Size 3



- Take care not to hit the sides as you insert the ceramic recuperator into the radiant tube. Tighten the nuts in a crosswise fashion, torque: 46 Nm.
- When installing, ensure that the components are sealed tightly.



- Tighten the nuts crossways using a torque of 20 Nm.




- Insert the "Flameless" gas lance using slow "rotary movements to and fro" and secure it using a torque of 40 Nm. There is a copper sealing ring under the gas lance adapter.

3.4 Heat guard

- During operation, the burner body and flue gas connector can reach surface temperatures of over 80°C (176°F).
- We recommend that warning signs and a contact guard be fitted, for example made of perforated sheet metal.
- Do not insulate the burner body and flue gas connector to prevent material overheating.

4 GAS AND AIR PIPES

Gas connection (GA) and air connection (LA)



LA1: Primary air connection

LA2: Secondary air

GA1: Gas connection for Flame mode

GA2: Gas connection for Flameless mode

Cooling air connection using LA1

- To increase the air volume in Cooling mode if required.
- The primary air connection LA1 can be used as an option for an increased volume of cooling air.
- The cooling air is connected on the straight bore of a T-piece using an elbow to the burner (an angle would generate excessive pressure loss).

- The burner primary air is then connected to the side inlet of the T-piece.




Table of threaded connections


Burner	GA1	GA2	LA1	LA2
ECOMAX LE 1	Rp 1/2"	G 1/2"	Rp 1 1/2"	Rp 1 1/2"
ECOMAX LE 2	Rp 1/2"	G 1/2"	Rp 1 1/2"	Rp 1 1/2"
ECOMAX LE 3	Rp 1/2"	G 1/2"	Rp 1 1/2"	Rp 2"

- Install flexible tubes or bellows units to prevent mechanical stress or transmission of vibration.
- Ensure that the gaskets are undamaged.

⚠ DANGER

Risk of explosion!

- Ensure the connection is air-tight.
- The gas insert together with the intermediate flange can be rotated in 90° increments if necessary.
- We recommend replacing all the gaskets that are removed to rotate the gas insert.
- If necessary, the secondary air connection may be repositioned. The burner has three secondary air connections, two of which are sealed with blind flanges.




4.1 Restrictors


- The appropriate restrictors are to be fitted in the fuel gas supply lines (Flame mode and Flameless mode) to adjust the burner.
- The air volume flows (primary air/total air) are adjusted directly on the air valves. The purge air is supplied without an additional restrictor (purge air nozzles are integrated in the burner).

4.2 Purge air connections

- The electrode and the gas lance must be cooled and purged with air.



- The purge air must be branched off upstream of the air control valve, for example at the inlet of the air solenoid valve. The gas lance for Flameless mode must be purged using a separate supply line.
- The purge air connections are located on the gas flange of the burner.
- The nozzle for electrode purge is integrated in the gas flange. The purge air nozzle for the "Flameless" gas lance is mounted on the outside of the gas flange. It is equipped with a filter and a pressure test nipple for checking for dirt (see Maintenance for further details). There is no need to set the purge air volumes.
- A UV sensor, if there is one, must be purged by a separate air supply line (see figure).





5 WIRING

⚠ DANGER

Electric shocks can be fatal!

- Before working on possible live components, ensure the unit is disconnected from the power supply.
- The flame is monitored by a combined flame rod/spark electrode as standard on the burner ECO-MAX LE.
- Flame control with a UV sensor is not necessary for the burner, but can be done if desired. In this case, we recommend a UV sensor UVS 10 with a lens and a purge air connection be used.

- An adapter set (Order No. 75459651), which must be ordered separately, is available for installing the UVS 10.
- For high temperature operation without flame control using ionization or a UV sensor, the air flow must be monitored by a pressure switch.
- We recommend an ignition transformer ≥ 7.5 kW, ≥ 20 mA.
- For the ignition/ionization cable, use (unscreened) high-voltage cable: FZLSi 1/6 up to 180°C (356°F), Order No. 04250410, or FZLK 1/7 up to 80°C (176°F), Order No. 04250409.
- Length of cable: max. 5 m, recommended < 1 m.
- Lay cable individually and not in a metal conduit.
- Install cable well away from main cables and interference from electromagnetic sources.
- In particular, avoid external electrical interference when using ionization control.
- For UV control, route the ignition cable separately from the UV cable.



- 4 Connect the PE wire for grounding to the gas insert. Route the PE wire from the gas insert directly to the connection on the automatic burner control unit.
- 5 Bend the wire-end ferrule through 45° to prevent the PE wire from touching any hot surfaces.

⚠ WARNING

High-voltage risk!

- It is essential that a high-voltage warning label be attached to the ignition/ionization cable.
- For more detailed information on how to wire the ignition/ionization cable, refer to the operating instructions and connection diagrams of the automatic burner control unit and ignition transformer.
- For further information about using a UV sensor, refer to the relevant operating instructions.

6 PREPARING COMMISSIONING

6.1 Safety instructions

- Agree on settings and commissioning of the burner with the system operator or manufacturer.
- Check the entire system, upstream devices and electrical connections.
- Note the operating instructions for individual controls.

⚠ DANGER

Risk of explosion!

- Gas pressure upstream of the burner gas valves (pressure in the gas pressure control system) must be **10 mbar** higher than the fan air pressure. This ensures that the slow ingress of air flow into the combustion gas is prevented in the event of a fault due to a blocked flameless gas lance.
- Please observe the appropriate precautions when igniting the burner.
- Pre-purge the furnace chamber or radiant tube with air (5 x volume) before every ignition attempt.
- Fill the gas line to the burner carefully and correctly with gas and vent it safely into the open air – do not discharge the test volume into the furnace chamber.

⚠ DANGER

Risk of poisoning!

- Open the gas and air supply so that the burner is always operated with excess air – otherwise CO will form in the furnace chamber. CO is odourless and poisonous! Conduct a flue gas analysis.
- The burner must only be commissioned by authorized trained personnel.
- If the burner does not ignite even though the automatic burner control unit has been switched on and off several times: check the entire system.

6.2 Determining the gas and combustion air flow rates

$$Q_{\text{Gas}} = P_B / H_i$$

$$Q_{\text{Air}} = Q_{\text{Gas}} \cdot \lambda \cdot L_{\text{min}}$$

- Q_{gas} : Gas flow rate in m^3/h (ft^3/h)
- P_B : Burner capacity in kW (BTU/h)
- H_i : Gas heating value in kWh/m^3 (BTU/ ft^3)
- Q_{air} : Air flow rate in $\text{m}^3(\text{n})/\text{h}$ (SCFH)
- λ : Lambda, air index
- L_{min} : Minimum air requirement in $\text{m}^3(\text{n})/\text{m}^3(\text{n})$ (SCF/SCF)
- Information on the gas quality supplied can be obtained from the gas supply company.

Common gas qualities

Gas type	Heating value		L _{min} m ³ (n)/ m ³ (n) (SCF/ SCF)
	H _u	H _o	
	kWh/ m ³ (n)	BTU/ SCF	
Natural gas H	11.0	1114	10.6
Natural gas L	8.9	901	8.6
Propane	25.9	2568	24.4
Low calorific value gas	1.7–3	161– 290	1.3–2.5
Butane	34.4	3406	32.3

- Data in kWh/m³(n) refer to the lower heating value H_u and data in BTU/SCF refer to the higher heating value H_o (gross calorific value).
- A minimum air excess of 20% (lambda = 1.2) should be set in a cold furnace for initial adjustment since the air volume falls as the temperature rises.
- Fine adjustment should be carried out at max. furnace temperature and at as high a capacity demand as possible.

6.3 Notes on the flow rate curve


- If the gas density in the operating state differs from that reflected in the flow rate curve, convert the pressures according to the local operating state.

$$P_B = P_M \cdot \frac{\delta_B}{\delta_M}$$

- δ_M : Gas density reflected in the flow rate curve in kg/m³ (lb/ft³)
- δ_B : Gas density in operating state in kg/m³ (lb/ft³)
- P_M : Gas pressure reflected in the flow rate curve
- P_B : Gas pressure in operating state

6.4 Determining the gas and combustion air settings

- In Flameless mode (Low NOx mode), the primary air supply is closed by closing the primary air valve. By reducing the total air volume, the capacity of the burner in Flameless mode is also reduced.
- In Flameless mode, the air flows into the burner through the secondary air connection.
- By using an air valve, the primary/secondary pressure levels change and the combustion air volume is reduced in Flameless mode.
- By using an air butterfly valve instead of an air valve, the capacity can be adjusted constantly or independently of the operating mode (Flame/Flameless).
- The burner features an orifice in the gas flange (GA1) for Flame mode.
- An orifice (VMO) is required in the total air supply line to measure the total air volume. An orifice (VMO) is also required to adjust the gas volume in Flameless mode.
- Adjustment is made on the basis of the flow rate-dependent pressure differential. The required pressure differentials for gas and air are shown in the burner diagram.




- Ensure an undisturbed flow to the total air orifice VMO.
- Elbows, angles or screw unions may be used in the gas flange of the gas circuit for Flame mode GA1.

⚠ WARNING

CO formation in combustion chamber
Incorrect burner settings may result in sub-stoichiometric burner operation. CO is odourless and poisonous!
– A flue gas analysis should be conducted.

6.5 Coarse adjustment of the combustion air volume

- The ECOMAX LE primary air restrictor on the gas flange is preset for the rated capacity on delivery using spacer washers.



- If a different burner capacity is to be used, remove a spacer washer as shown in the table.

Size	Capacity in Flameless mode [kW]	Spacer washer [mm]
1	22–36	No washer
2	36–45	No washer
2	45.1–60	No washer
3	60–75	No washer
3	75.1–83	3
3	83.1–90	4.7
3	90.1–100	3 + 4.7

- Air measuring nipple L, outside dia. = 9 mm (0.35").

Measuring the differential air pressure


- 1 Close the gas supply on the manual valve upstream of the gas valve group.

⚠ DANGER


Risk of explosion!

- Prevent the uncontrolled flow of gas into the radiant tube.


2 Measure the differential pressure on the total air measuring orifice VMO downstream of the total air valve or the total air butterfly valve.




→ Control with 2 air valves (jump in capacity)



→ Control with butterfly valve (constant or variable capacity)



→ Control with 3 air valves (constant or variable capacity)



3

4 Switch the burner control unit to Manual mode.

5 Start pre-purge.

→ Presetting of the primary air volume at the air valve (VAA): restriction as shown in the table.


Burner	Valve in Flame mode	Restriction [revolutions]
ECOMAX LE 1	VAA	4.5
ECOMAX LE 2	VAA	Fully open
ECOMAX LE 3	VAA	Fully open

→ Presetting of the total air volume for Flame mode at rated capacity, adjustment on the total air restrictor:

Burner	Differential pressure on the total air orifice [mbar]
ECOMAX LE 1	6
ECOMAX LE 2	5.5
ECOMAX LE 3	7

6 End pre-purge.


7 Check the purge air pressure at the gas insert. Make a note of the value and compare it with values from the initial commissioning procedure and/or the last maintenance process. In the event of a discrepancy: check purge air nozzles for blockages, see page 10 (8 Maintenance).




6.6 Preparing the gas pressure measurement

1 Connect all measuring devices to the burner for later adjustment.

- Leave the gas supply closed.
- 2** Read the differential pressure for the required gas flow rate (Flame mode) from the enclosed flow rate curve.
- 3** p1: gas pressure upstream of the measuring orifice, p2: gas pressure downstream of the measuring orifice. Measuring range: select approx. 15 mbar.
- Gas measuring nipple **G**, outside dia. = 9 mm (0.35 inch)).



- Loosen the screws 2 turns.



7 COMMISSIONING

Igniting and adjusting the burner

⚠ WARNING

Risk of burning!

Outflowing flue gases and burner components are hot.

- Attach warning signs and a contact guard.
- Ensure adequate ventilation of the combustion chamber before each burner start!
- Wear ear protection to protect yourself from harmful noise.
- When heating up for the first time, vapours may be emitted from gaskets or paint coatings, for example, which may cause unpleasant odours.
- The gas inlet pressure must be 10 mbar higher than the fan air pressure.

Coarse adjustment with the furnace cold

- 1** Limit the maximum gas volume.
- 2** The Flame mode gas restrictor is around half-open.
- 3** The Flameless mode gas restrictor must be fully closed.

⚠ DANGER

Risk of explosion and poisoning in case of burner adjustment with an air deficiency.

CO formation in the combustion chamber! CO is odourless and poisonous!

- Adjust the gas and air supply so that the burner is always operated with excess air.
- Conduct a flue gas analysis.
- 4** Open the gas supply. (Manual valve upstream of the gas solenoid valve group)
- 5** Ignite the burner in Flame mode.

- A cold start in the radiant tube may cause pulsation noise. This will disappear after the burner has been operating for 2 to 3 minutes.
- The safety time of the automatic burner control unit starts to elapse.
- 6** Check and adjust the Flame mode gas differential pressure.
- 7** Check and adjust the total air volume on the basis of the oxygen (cold start phase 4–5% O₂). Make the adjustment using the integrated restrictor in the total air valve or the total air butterfly valve.
- 8** If no flame is formed, reset the automatic burner control unit, purge the combustion chamber and ignite the burner again.

⚠ CAUTION

Material damage!

There must not be a combustible mixture in the combustion chamber.

- After a failed start or fault, pre-purge the combustion chamber and radiant tube with air (5 x volume) before attempting to ignite it again.
- The burner ignites and proceeds to normal operation.
- If no flame is formed after repeating the above steps multiple times – see page 13 (9 Assistance in the event of malfunction).

7.1 Tightness test

⚠ DANGER

Escaping gas!

Danger from a leakage at the gas connections.

- Check the gas connections on the burner for leaks immediately after commissioning the burner.



7.2 Adjustment with a hot furnace

- The fine adjustment of the burner should be carried out at a high furnace temperature and high capacity demand.
- 1** Heat the furnace.
- Monitor the O₂ value in the flue gas (FLUP). Avoid sub-stoichiometric operation of the burner.
- If necessary, adjust the settings of the total air on the basis of the oxygen value in the flue gas (generally 3% O₂).
- Flameless mode can only be adjusted if the furnace temperature is above 850°C (1560°F).

CAUTION

Risk of explosion!

Risk of explosion when starting Flameless mode in a cooled radiant heating tube (despite the high zone temperature).

- Do not purge the radiant tube before switching to Flameless mode.
- If a burner is to be switched to Flameless mode after a cooling process, a waiting time for reaching a temperature balance or brief Flame mode to reheat the radiant tube is required if the furnace is sufficiently hot.

- Switching to Flameless mode in Manual mode using the BCU is only possible using a laptop and BCSof.
- Fine adjustment can only be carried out by repeatedly switching between Flameless and Flame mode.
- 2 Open the gas restrictor for Flameless mode around halfway.
- 3 Switch the burner to Flameless mode using BCSof.
- 4 Check and adjust the Flameless mode gas differential pressure.
- 5 Check the total air volume using the oxygen value in the flue gas and adjust the air volume again if necessary. The adjustment is made using the total air valve or the air butterfly valve. The primary air volume must not be changed.
- 6 Switch off the burner.
- 7 Start the burner in Flame mode.
- 8 The capacity in Flame mode must be adjusted using the oxygen value in the flue gas. To do so, alter the Flame mode gas flow rate using the restrictor, while checking the oxygen value in the flue gas and adjusting it as required (generally 3% O₂).
- 9 The air volume in Flame mode has now been changed compared to Flameless mode. Do not change the adjustment on the total air valve for Flame mode.
- 10 If adjustment of the burner is not possible with the existing air pressure, change the capacity in Flame or Flameless mode, see page 7 (6.4 Determining the gas and combustion air settings).
- 11 Adjust the pressure switches of the air flow detector set for Flame and Flameless mode.

7.3 Pressure switches

- The Air flow detector-Set ECO LE for total air control with valve includes a pressure switch for Flame mode and a pressure switch for Flameless mode due to the change in capacity when switching over.
- The switching point when the burner is set to 3% O₂ should be set to around 80% of the differential pressure for the combustion air.
- Set the pressure switch set for flue gas monitoring (if installed) to the required pressure shown in the enclosed documentation.

7.4 Blocking and recording the settings

- 1 Produce a setting and maintenance report.

- 2 Remove the measuring devices and close off the test nipples – tighten the grub screws.
- 3 Block and seal the adjusting elements.
- 4 Induce a flame failure in Flame mode by closing the manual gas shut-off valve upstream of the gas valves. The flame failure fault must be detected and result in the gas valves being closed.
- 5 Stop the combustion air supply (without changing the flow adjustment) to check the air pressure switch function in **Flame mode**. The air pressure switch must switch and issue a fault signal which leads to the gas valves being closed.
- 6 Stop the combustion air supply (without changing the flow adjustment) to check the air pressure switch function in **Flameless mode**. The air pressure switch must switch and issue a fault signal which leads to the gas valves being closed.
- 7 Reset the burner control unit and switch on the burner again.
- 8 Check the O₂ value.
- 9 Switch off the burner.
- 10 Switch off Manual mode at the burner control unit.
- 11 The furnace control unit will take over control of the burner.

DANGER

Risk of explosion in case of CO being formed in the combustion chamber! CO is odourless and poisonous!

An incorrect change of the burner settings may change the gas/air ratio and lead to unsafe operating conditions:

- All interventions may only be carried out by qualified gas technicians.

8 MAINTENANCE

- Maintenance and function check every six months. If the media are highly contaminated, this interval should be reduced.

DANGER

Risk of explosion!

- Please observe the appropriate precautions when igniting the burner.
- Maintenance work on the burner must be carried out by authorized trained personnel only.

DANGER

Risk of poisoning!

- Open the gas and air supply so that the burner is always operated with excess air – otherwise CO will form in the combustion chamber. CO is odourless and poisonous! A flue gas analysis should be conducted.

DANGER

Risk of burning!

- Outflowing flue gases and burner components are hot.

→ We recommend that all the gaskets removed during maintenance work be replaced. The appropriate gasket set is available separately as a spare part.

1 Check the cable to the electrode.

2 Measure the ionization current.


→ The ionization current in Flame mode must be at least 5 μ A and must not vary.

→ Read off the ionization signal on the burner control unit.

Checking the purge air

3 Switch off the burner.

4 Measure the purge air pressure at the purge air nozzle.




5 Make a note of the value and compare it with values from the initial commissioning procedure and/or the last maintenance process.

→ If the pressure is lower at the purge air measuring nipple, this indicates that a purge air nozzle or filter is blocked. In this case: replace the filter and conduct a visual inspection of the purge air nozzle for blockages; if necessary, remove the purge air nozzles and remove the contamination. For mounting the purge air nozzle, use DVGW-approved sealant on the external thread which is screwed into the gas flange.

→ If the pressure is higher at the purge air measuring nipple: gas lance for Flameless mode is blocked.



6 Switch off the burner control unit.

7 Shut off the gas and air supply – do not change the restrictor settings.



10 If a borehole in the gas lance for Flameless mode is blocked, you must expect soot deposits in the “Flameless” gas lance. In this case, check the “Flameless” gas lance and clean it if necessary.


→ Carefully clear the gas lance with a pricking tool.



11 Install a new copper sealing ring under the gas lance adapter.

→ Insert the “Flameless” gas lance using slow “rotary movements to and fro” and secure it using a torque of 40 Nm.

8.1 Checking and replacing the spark electrode/flame rod




→ Ensure that the electrode length does not change.


3 Remove dirt from electrode or insulator.

4 Replace the electrode if the tip **3** or insulator **2** is damaged.

→ Before changing the electrode, measure the total length **L**.



6 Adjust spark plug and electrode rod to the measured total length **L**.




8.2 Checking the burner head and gas lance

→ The complete gas insert must be removed to check the burner head.

1 Disconnect the gas and primary air lines from the gas insert.

2 Disconnect the grounding cable.




4 Pull the gas insert **very slowly** and carefully out of the burner, see page 3 (3.3 Installation in the furnace).

→ Do not bang the gas insert against the internal ceramic air guide tube LFR during the removal process.


5 Place the gas insert in a safe place.

6 Check the burner head for dirt, wear and thermal damage and cracks; clean or replace if necessary.


8.3 Replacing the burner head



3 Loosen the lock nut.




4 Follow the reverse procedure when reassembling.




5 → Finally, align the first insulator on the electrode with the burner baffle plate.


6 Check the interior of the ceramic gas lance for soot deposits. Visually and using suitable tools: insert tool into the ceramic part of the gas lance by a length of > 150 mm. Clean the purge air nozzles which have become blocked by soot.



8.4 Checking the body insulation




4 If possible, carefully check the body insulation from the front for signs of damage. To do this, carefully remove the gas insert, air guide tube and burner.



6 If the insulation is worn or damaged, it must be replaced.

7 Remove the gas insert and air guide tube.



10 Ensure that the flue gas insulation is installed in the correct position. $a < b$



11 Follow the reverse procedure when reassembling.

8.5 Checking/replacing the air guide tube LFR and recuperator

⚠ CAUTION

Risk of breakage.


- For components made of ceramic material – avoid impacts.



→ To check the body insulation carefully and to replace the recuperator, remove the burner and suspend it vertically, e.g. on two beams.

4 Remove the recuperator:

Ceramic recuperator



d Check the recuperator for damage.


→ If any ceramic components are damaged, they must be replaced.

e Follow the reverse procedure when reassembling.

→ Ensure that the cup springs are installed facing the correct direction (curve towards the nut).

f Tighten the nuts in a crosswise fashion, torque: 5 Nm.

Metallic recuperator




c Check the recuperator for damage.

d Follow the reverse procedure when reassembling.

→ Ensure that the cup springs are installed facing the correct direction (curve towards the nut).

- e Tighten the nuts in a crosswise fashion, torque: 8–10 Nm.
- 5 Test the compression springs. It must be possible to push the pressure flange towards the gas flange with force. Replace the springs if necessary. Then tighten the screws with a torque of 10 Nm.
- 6 Before assembly, place a new gasket cord in the pressure flange. The ends of the gasket cord must lie flat on each other.



- 7 Assemble the burner, see page 3 (3.3 Installation in the furnace)
- 8 Connect the ignition cable.
- 9 Connect the grounding cable.
- 10 Connect the gas line to the gas insert.
- 11 Connect voltage to the system.
- 12 Check for tightness, see page 9 (7.1 Tightness test).
- 13 Open the gas and air supply.
- 14 Start the burner, see page 9 (7 Commissioning).

⚠ DANGER

Risk of explosion and poisoning in case of burner adjustment with insufficient air!

- Adjust the gas and air supply so that the burner is always operated with excess air – otherwise CO will form in the combustion chamber. CO is odourless and poisonous! Conduct a flue gas analysis.
- 15 Produce a maintenance report.

9 ASSISTANCE IN THE EVENT OF MALFUNCTION

⚠ DANGER

Electric shocks can be fatal!

- Before working on possible live components, ensure the unit is disconnected from the power supply.

⚠ DANGER

Risk of injury!

Burner heads have sharp edges.

- Burner inspection must only be performed by authorized trained personnel.

→ If no issues are found when checking the burner, proceed to the automatic burner control unit and check for faults in accordance with the relevant operating instructions.

? Fault

- ! Cause
 - Remedy

? Burner does not function.

- ! Valves do not open.
 - Check the voltage supply and wiring.
- ! Gas inlet pressure is too low.
 - Check the filter for dirt.
 - Check the gas supply.
- ! Air inlet pressure is too low.
 - Check the fan and air supply.
- ! Gas and air pressures on the burner are too low.
 - Check the restrictors.
 - Check/adjust the start rate setting, see operating instructions for solenoid valve.
- ! Automatic burner control unit does not function correctly.
 - Check the device fuse.
 - Note the automatic burner control unit operating instructions.
- ! Short-circuit of the UV sensor.
 - Replace the UV sensor.
 - Note the UV sensor operating instructions.
- ! Automatic burner control unit signals a fault.
 - Check the ionization cable.
 - Check the ionization current. The ionization current must be at least 5 μ A – stable signal.
 - Check whether the burner is adequately grounded.
 - Note the automatic burner control unit operating instructions.
- ! No ignition spark is created.
 - Check the ignition cable.
 - Check the voltage supply and wiring.
 - Check whether the burner is adequately grounded.
 - Check the electrode – see page 10 (8 Maintenance).
- ! Defective insulator on the electrode, ignition spark jumps over incorrectly.
 - Check the electrode.
- ! The ignition spark may jump over incorrectly if there is inadequate electrode purge air.
 - An adequate flow of purge air is audible from the noise at the electrode installation point in the gas flange when the electrode has been removed; if this noise is not clearly audible: remove the electrode purge air supply line, check the purge air outlet from the now open purging hose and clean any dirt in the internal purge air hole in the gas flange if required (clear the purge air hole $d = 2.5$ mm using a suitable tool).
- ? No gas in Flame mode.**
- ! Valve plugs for gas in Flame mode and gas in Flameless mode reversed.
 - Non-combusted gas gets into the radiant tube when the burner starts. Conduct a purge after incorrect ignition.

? No air in Flameless mode.

- ! Total air and primary air valve plugs reversed.
- ? **Burner performs a fault lock-out after operating faultlessly in normal operation.**
- ! Incorrect gas and air flow rate settings.
 - Check the differential pressures for gas and air.

- ! Automatic burner control unit signals a fault.
 - Check the ionization cable.
 - Check the ionization current. The ionization current must be at least 5 µA – stable signal.

- ! Burner head is dirty.
 - Clean gas and air bore holes and air slots.
 - Remove deposits.


- ! Excessive pressure fluctuations in the combustion chamber.
 - Ask Honeywell Kromschroder for control concepts.

? Furnace cools down in Flameless mode.

- ! Gas lance for Flameless mode blocked.
 - Remove gas lance and check it; clean or replace it as necessary, see page 10 (8 Maintenance).


10 ACCESSORIES

10.1 Flue gas connector FLUP



The FLUP is not supplied with the ECOMAX LE and must be ordered separately.

10.2 Ceramic radiant tube SER-C




- 1 Burner gasket
- 2 Flange connection
- 3 Radiant tube (SiSiC)
- 4 Mounting gasket

For heat treatment processes in which combustion gases must be kept separate from the product. The patented flange connection is air-tight.
Material: SiSiC, max. application temperature: 1300°C (2372°F).

The SER-C is not supplied with the ECOMAX LE and must be ordered separately.

10.3 Flue gas guide tube FGT for SER




Used to guide the flue gases if smaller burners are used than are standard for the radiant tube diameter. The flue gas guide tube ensures sufficient heat exchange via the burner recuperator.

Material: vacuum moulded pulp for ECOMAX LE..C or metal for ECOMAX LE..M

Available on request in different sizes suitable for the SER radiant tube and ECOMAX LE burner sizes.

10.4 Segmented flame tube SICAFLEX




Segmented ceramic flame tubes to guide hot flue gases in radiant tubes.

Material: SiSiC.

The SICAFLEX® is not supplied with the ECOMAX LE and must be ordered separately.

10.5 FlameCone



Designation	Order No	SER-C	SER-M di
FlameCone ECO-LE-1C-129-135-550-H	34340812	SER-C 142/128	
FlameCone ECO-LE-2C-149-155-550-H	34340813	SER-C 162/148	
FlameCone ECO-LE-3M/C-185-207-550-H	34340800	SER-C 202/188	
FlameCone ECO-LE-1M-128-140-550-H	34340801		128-140
FlameCone ECO-LE-1M-136-149-550-H	34340807		136-149
FlameCone ECO-LE-2M-147-161-550-H	34340802		147-161
FlameCone ECO-LE-2M-156-169-550-H	34340811		156-169
FlameCone ECO-LE-3M/C-185-207-550-H	34340800		185-207

The FlameCone is required in the radiant tube for Flameless mode. It is connected to the SICAFLEX by a bayonet joint.

10.6 Adapter set UVS 10

Burner	Designation	Order number
ECOMAX LE 1-3	Adapter set UVS 10 ECO LE 1-3	75459651

11 TECHNICAL DATA

Heating: indirect in radiant tube.

Control type: On/Off (or Low/High/Off for NFPA).

Adjusting range: 60 to 100%.

Flame velocity: approx. 130 to 170 m/s
(430 to 560 ft/s).

Flame control: with flame rod (UV control as an option).

Ignition: direct spark ignition.

Burner	Recuperator	Max. flue gas temperature at recuperator inlet
ECOMAX LE..C	Ceramic (SiSiC)	1260°C (2300°F)
ECOMAX LE..M	metallic	1150 °C (2100 °F)

Burner	Capacity [kW]	Flame length [mm]*
ECOMAX LE 1	36	300
ECOMAX LE 2	48	300
ECOMAX LE 2	60	400
ECOMAX LE 3	100	450

Burner	Capacity [kBtu/h]	Flame length [ft]*
ECOMAX LE 1	136	1
ECOMAX LE 2	182	1
ECOMAX LE 2	227	1.3
ECOMAX LE 3	378	1.5

* Visible range for natural gas operation in the open air, max. connection rating and air index 1.15.

If the burners are used at geodetic altitudes of over 500 m (1645 ft) above MSL, the possible capacity will be lower as a result of the reduced density of gas and air. Guide value: 5% per 1000 m (3290 ft) above MSL.

12 LOGISTICS

Transport

Protect the unit from external forces (blows, shocks, vibration).

Transport temperature: see page 15 (11 Technical data).

Transport is subject to the ambient conditions described.

Report any transport damage on the unit or packaging without delay.

Check that the delivery is complete.

Storage

Storage temperature: see page 15 (11 Technical data).

Storage is subject to the ambient conditions described. Storage time: 6 months in the original packaging before using for the first time. If stored for longer than this, the overall service life will be reduced by the corresponding amount of extra storage time.

Packaging

The packaging material is to be disposed of in accordance with local regulations.

Disposal

Components are to be disposed of separately in accordance with local regulations.

13 DECLARATION OF INCORPORATION

according to 2006/42/EC, Annex II, No. 1B
The product "Burner for gas ECOMAX® LE 3C" is a partly completed machine pursuant to Article 2g and is designed exclusively for installation in or assembly with another machine or other equipment. The following essential health and safety requirements in accordance with Annex I of this Directive are applicable and have been fulfilled:
Annex I, Articles 1.1.3, 1.1.5, 1.3.2, 1.3.3, 1.3.4, 1.3.7, 1.3.8, 1.5.2, 1.5.4, 1.5.10, 1.7.3, 1.7.4
The relevant technical documentation has been compiled in accordance with part B of Annex VII and will be sent to the relevant national authorities on request as a digital file.

The following (harmonized) standards have been applied:

- EN 746-2:2010 – Industrial thermoprocessing equipment; Safety requirements for combustion and fuel handling systems
- EN ISO 12100:2010 – Safety of machinery – General principles for design – Risk assessment and risk reduction (ISO 12100:2010)

The partly completed machine may only be commissioned once it has been established that the machine into which the product mentioned above is to be incorporated complies with the provisions of the Machinery Directive 2006/42/EC. Elster GmbH

Einbauerklärung

nach 2006/42/EG, Anhang II, Nr. 1B

/ Declaration of Incorporation

/ according to 2006/42/EC, Annex II No. 1B

Folgendes Produkt / The following product:

Bezeichnung
Description
Typenbezeichnung / Type
Maschinenname / Branding

Brenner für Gas
Burner for gas
ECOMAX LE 3-5-C

krom/
schroder

ist eine unveränderliche Maschine nach Artikel 2g und ausschließlich zum Einbau in oder zum Zusammenbau mit einer anderen Maschine oder Ausrüstung vorgesehen.
is a partly completed machine pursuant to Article 2g and is designed exclusively for installation in or assembly with another machine or other equipment

Folgende grundlegende Sicherheits- und Gesundheitsschutzanforderungen gemäß Anhang I dieser Richtlinie kommen zur Anwendung und werden eingehalten.
The following essential health and safety requirements in accordance with Annex I of this Directive are applicable and have been fulfilled

Anhang I, Artikel / Annex I, Article
1.1.3, 1.1.6, 1.2.2, 1.2.3, 1.2.4, 1.3.7, 1.3.8, 1.5.2, 1.5.4, 1.5.10, 1.7.3, 1.7.4

Die speziellen technischen Unterlagen gemäß Anhang VII B sind erstellt und werden der zuständigen nationalen Behörde auf Verlangen in elektronischer Form überreicht.
The relevant technical documentation has been compiled in accordance with part B of Annex VII and will be sent to the relevant national authorities on request as a digital file

Folgende (harmonisierte) Normen wurden angewandt: / The following (harmonized) standards have been applied:
EN 146-2:2010 – Industrielle Thermopressanlagen – Sicherheitsanforderungen an Pressen und Spannschließungssysteme
– Industrial thermoprocessing equipment – Safety requirements for combustion and fuel handling systems
EN ISO 12100:2010 – Sicherheit von Maschinen – Allgemeine Gestaltungsfehler – Risikoanalyse und Risikominimierung (ISO 12100:2010)
– Safety of machinery – General principles for design – Risk assessment and risk reduction (ISO 12100:2010)

Folgende EU-Richtlinien werden erfüllt: / The following EU directives are fulfilled:
RoHS 1 (2011/65/EU)
RoHS 2 (2015/850/EU)

Die unveränderliche Maschine darf erst dann in Betrieb genommen werden, wenn festgelegt wurde, dass die Maschine, in der die oben beschriebene Produkt eingebaut werden soll, den Bestimmungen der Richtlinie für Maschinen (2006/42/EG) entspricht.

The partly completed machine may only be commissioned once it has been established that the machine into which the product mentioned above is to be incorporated complies with the provisions of the Machinery Directive (2006/42/EC).

Lotte (Stempel)

14.07.2021
Datum / Date

S. Runde / S. Escher
Konstrukteur / Designer

S. Runde / S. Escher sind berechtigt, die speziellen technischen Unterlagen gemäß Anhang VII B zusammenzustellen.
S. Runde / S. Escher are authorized to compile the relevant technical documentation according to Annex VII B

Elster GmbH
Postfach 28 08
42699 Solingen
Deutschland
Telefon (0212) 14 14 14
Fax (0212) 14 14 14
www.kromschroeder.com

14 CERTIFICATION

14.1 Eurasian Customs Union



The products ECOMAX LE meet the technical specifications of the Eurasian Customs Union.

FOR MORE INFORMATION

The Honeywell Thermal Solutions family of products includes Honeywell Combustion Safety, Eclipse, Exothermics, Hauck, Kromschroder and Maxon. To learn more about our products, visit ThermalSolutions.honeywell.com or contact your Honeywell Sales Engineer.
Elster GmbH
Strothweg 1, D-49504 Lotte
T +49 541 1214-0
hts.lotte@honeywell.com
www.kromschroeder.com

Global centralized service deployment coordination:
T +49 541 1214-365 or -555
hts.service.germany@honeywell.com

Translation from the German
© 2022 Elster GmbH

